

# SPRAYER CALIBRATION WORKSHEET

Sprayer ID: \_\_\_\_\_ DATE: \_\_\_\_\_

## A) DISTANCE THE SPRAYER MOVES IN ONE MINUTE

\_\_\_\_\_ SECONDS TO COVER 88 FEET - 1<sup>ST</sup> TIME [RUNNING START]

\_\_\_\_\_ SECONDS TO COVER 88 FEET - 2<sup>ND</sup> TIME [RUNNING START]

\_\_\_\_\_ AVERAGE TIME in seconds [USE BELOW]

60 / \_\_\_\_\_ = \_\_\_\_\_ MPH \* 88ft = A) \_\_\_\_\_ ft traveled in one minute  
Average Time

## B) EFFECTIVE BOOM WIDTH (IN FEET)

\_\_\_\_\_ NUMBER OF NOZZLES

\_\_\_\_\_ SPACING BETWEEN NOZZLES [in inches]

\_\_\_\_\_ # NOZZLES \* \_\_\_\_\_ SPACING = \_\_\_\_\_ INCHES

\_\_\_\_\_ INCHES / 12 = B) \_\_\_\_\_ BOOM WIDTH IN FEET

## C) AREA COVERED IN ONE MINUTE

B 

<- A ->
C

A) \_\_\_\_\_ ft traveled in 1 min times B) \_\_\_\_\_ ft of boom width = C

C = \_\_\_\_\_ ft<sup>2</sup> = area covered by spray rig in 1 minute

## D) TIME TO SPRAY ONE ACRE

*Divide C into 43,560 ft<sup>2</sup>* [remember 43,560 ft<sup>2</sup> = 1 acre]  
to find how many minutes it takes your rig to cover 1 acre

43,560 ft<sup>2</sup>/acre = D) \_\_\_\_\_ minutes to spray 1 acre

C = \_\_\_\_\_

**F) AMOUNT OF SPRAY PER MINUTE    Spray rig's Gallons Per Minute [GPA]**

Collection from nozzles: Length of time : \_\_\_\_sec [*use to convert to one minute*]

Amount collected per nozzle: in ounces

1<sup>st</sup> trial

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

2<sup>nd</sup> trial

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

Average collected per nozzle = \_\_\_\_\_ \* # nozzles = E) \_\_\_\_\_ total ounces

**BE SURE TO FIND TOTAL OUNCES PER MINUTE** and divide by 128 oz/gal

E= \_\_\_\_\_ oz/minute = **F) \_\_\_\_\_ GPM** [gallons per minute for the BOOM]  
 128 oz/gal

**GALLONS PER ACRE CALCULATION**

Take the spray rig's GPM times the minutes to cover 1 acre  
 = the GPA [Gallons Per Acre] of your spray rig

**F) \_\_\_\_\_ GPM \* D) \_\_\_\_\_ Minutes/acre =**

**\_\_\_\_\_ the GPA [Gallons Per Acre] of your spray rig**

*A quick formula check for the above method is*

$\text{GPA} = \frac{5940 * \text{GPM for one nozzle}}{\text{MPH} * \text{nozzle spacing in inches}}$
--